
Assembly


AR-416 2017/02/25 Revised: 2017/06/03

(1) Place back boards (BD8-9) in parallel on flat, horizontal plane



Assembly 1/10


(2) Place shelves (BD1-5) and side boards (BD6-7) on back boards (BD8-9)




(3) Fix shelves (BD1-5), side boards (BD6-7) and back boards (BD8-9) to each other with protective tape

Assembly 2 / 10

(4) Mark the positions of guide holes with piercer




- (5) Disassemble the assembly
- (6) Make the guide holes with phi 2.5 drill



- (7) Repeat the steps 1 & 2
- (8) Glue all the parts each other with wood bond

Assembly 3 / 10


(9) Screwed all the parts each other



(10) Fix aluminum channels CH1,2,3 on shelves BD2,3,4


MiniRack

(1) Place back boards (BD17-18) in parallel on flat, horizontal plane




Assembly 4 / 10

(2) Place shelf (BD14) and side boards (BD15-16) on back boards




- (3) Fix the parts each other with protective tape and align them
- (4) Put top and bottom boards (BD12-13) in place and fix them with protective tape




Assembly 5 / 10

(5) Mark the positions of guide holes for screws with piercer




- (6) Disassemble MiniRack
- (7) Drill the guide holes with phi 2.5 drill



Assembly 6 / 10


(8) Fix slide rails (AP-1120C) on side boards (BD15-16)




- (9) Repeat step-1
- (10) Glue back boards(BD17-18), side boards (BD15-16) and shelf (BD14) together with wood bond
- (11) Glue top and bottom boards (BD12-13) to the assembly with wood bond

Assembly 7 / 10

(12) Fix the assembly with screws




(13) Place bottom board (BD19), side boards (BD20-21), front board (BD22) and back board (BD23) on work bench




(14) Fix the parts each other with protective tape

Assembly 8 / 10


(15) Mark the positions of guide holes for screws with piercer



- (16) Disaasemble the assembly
- (17) Make guide holes for screws



- (18) Repeat step-13
- (19) Glue parts each other with wood bond
- (20) Fix the assembly with screws



Assembly 9 / 10

(21) Attach drawer to the main body temporarily and check it out



[End of sheet]

Assembly 10 / 10